0006010
Enter Setup

USB Country Keyboard Types

Keyboard layouts vary from country to country. The default setting is U.S. keyboard.

1103001
**** U.S.**

1103002
Japan

1103003
Denmark

1103004
Finland

1103005
France

1103006
Turkey_F

1103007
Italy

1103008
Norway

0006000
**** Exit Setup**

0006010
Enter Setup

1103222
Spain

1103226
Turkey_Q

1103227
UK

1103209
Austria, Germany

1103202
Belgium

1103220
Russia

1103223
Sweden

1103218
Portugal

0006000
**** Exit Setup**