

Description	Setting	Setting Barcode	Code ID
Transfer Key Code of Function Key Under Communication Mode	Disable	 A022A	kapatmak
	Enable	 A022B	açmak